

STG / STV / STU High Performances Green & UV Triggered Microchip Series



KEY FEATURES

- Ultra-short pulses down to 350ps
- 532nm, 355nm and 266nm
- Single-shot to 100kHz
- Multi-kW peak power
- Excellent beam quality
- Efficient, air-cooled
- · Sealed package, extremely long life

For generating high peak power pulses of a few hundred picoseconds, microchip lasers are economical, compact, and reliable. Visible and UV wavelength are generated from the harmonic conversion of an IR passively Q-switched Nd:YAG microchip engine, within a sealed package ensuring incredibly long lifetime even in harsh industrial environment.

The triggered series offer the highest peak power and shortest pulses of the entire Microchip family, and span the full wavelength spectrum down to 266nm. With these devices, the user is able to trigger pulse emission on demand from single-shot to 4kHz.

APPLICATIONS

- Instrumentation
 - Ranging
 - Differential absorption LIDAR
 - Super-continuum generation
 - Distributed temperature sensing
 - Raman spectroscopy

- Biophotonics
 - Micro-dissection of cells
 - Brain nanosurgery
 - Protein cross-linking

All information contained herein is believed to be accurate and is subject to change without notice. Teem Photonics may not be held liable for its use. Teem Photonics, its subsidiaries and affiliates, reserve the right to modify or withdraw, at any time and without any notice, specifications, product design, product component. Some options may not be available for all products. Please contact Teem Photonics for details. May 2024.



	STG-03E-1x0	STG-05E-1x0 [*]	STV-01E-1x0	STV-02E-1x0	STU-01E-1x0
Wavelength	532nm	532nm	355nm	355nm	266nm
Maximum Repetition Rate RR _{max} ⁽¹⁾	4 kHz	1 kHz	4 kHz	4 kHz	4 kHz
Constant Pulse width (FWHM) ⁽²⁾	<0.5ns	<0.7ns	<0.4ns	<0.6ns	<0.4ns
Output Energy	>3 µJ	>5 µJ	>1 µJ	>2 µJ	>1 µJ
Peak Power	>6kW	>7.1kW	>2.5kW	>4kW	>2kW
PCD ⁽³⁾	<70µs		<100µs	<100µs	<100µs
PCD jitter	<±1.5µs		<±1.5µs	<±1.5µs	<±1.5µs
Short term (10min) power stability ⁽⁴⁾	<±1%	<±1%	<±2%	<±2%	<±2%
Long term (6 hrs) power stability ⁽⁴⁾	<±3%	<±3%	<±5%	<±5%	<±5%
Spectral properties	Single Longitudinal Mode Linewidth: 0.8pm	Single Longitudinal Mode	Single Longitudinal Mode Linewidth: 0.5pm	Single Longitudinal Mode Linewidth: 0.3pm	Single Longitudinal Mode Linewidth: 0.3pm
Beam profile Full angle divergence	Gaussian TEM00	Gaussian TEM00	Gaussian TEM00	Gaussian TEM00	See note (8)
Horizontal@1/e ² Vertical@1/e ²	10±2mrad 9±2mrad	10±2mrad 9±2mrad	11±2mrad 7±2mrad	11±2mrad 7±2mrad	11.5±2mrad 0.65±0.25mrad
M ²⁽⁵⁾	<1.3	<1.3	<1.3	<1.3	<1.4
Beam ellipticity ⁽⁶⁾	<1.3	<1.3	<1.3	<1.3	N/A
Main Lobe Gaussian Fit ⁽⁷⁾	N/A	N/A	N/A	N/A	>85%
Polarization	Linear PER>20dB	Linear PER>20dB	Linear PER>20dB	Linear PER>20dB	Linear PER>20dB
Laser head dimensions	See mechanical drawings on pages 4, 5 and 6				
Laser head weight	300g	300g	500g	500g	500g
Options (table p3)	0,1,2,3,4	0,1,2,3,4	0,1,2,3,4,C	0,1,2,3,4,C	0,1,2,3,4,C
Options included	S	S	S	S	S

* The specifications will be confirmed after the Beta phase only. For the moment, the specifications are preliminary, which means that the final laser parameters might be different than the current specifications. NOTES

(1) See options p3

(1) See options p3
(2) Measured with 1Ghz photodiode and 1GHz/10GS/s oscilloscope.
(3) PCD = Pulse Creation Delay, the delay between the trigger command and the effective pulse firing
(4) For temperature variation < ± 3°C and < 3°C/hour, stability is measured with calorimeter – detector band [DC, 2Hz]
(5) Mean average value M = √(XY), X and Y being respectively the major and minor axis of the ellipse
(6) Beam ellipticity is calculated as the ratio of the main axis far field divergence

(7) Measurement performed in the far field with a WincamTD-U series camera

(8) Beam exhibits different profile in horizontal (Gaussian) and vertical ((sin x /x)² in far-field) plans



COMPLEMENTARY INFORMATION & OPTIONS

Environment Parameters					
Operating Temperature Range	0-50℃ for STG 15-35℃ for STV and STU				
Maximum Laser Head Baseplate Temperature	50°C for STG 40°C for STV and STU				
Maximum Power Consumption	<40W				
Laser Head Thermal Dissipation	<15W				
Storage Temperature	0-50°C				
Shock of 11ms according to IEC 68-2-27, non operating	25g				
Vibration 5Hz to 500Hz sinusoidal according to IEC 68-2-6	2g				

Certification					
Laser classification according to IEC 60825-1:2007	3B Except STU-01E : 4				
CDRH	Yes, if used with a MLC-03A-DP1 controller				
RoHS	Yes				

Options				
Fixed Repetition Rate = RR _{max}	-10x version			
Fixed Repetition Rate ≠ RR _{max}	-11x version ; RR to be chosen over 10Hz-RR $_{\rm max}$			
External Variable Repetition Rate	-12x version ; single shot to RR_{max} , 1 optimized RR value			
External Variable Multi-Repetition Rate	-13x version ; single shot to RR_{max} , 3 optimized RR values			
External Continuous Variable Repetition Rate	-14x version ; optimized over [10Hz-RRmax] if RRmax ≤ 2kHz; or [10Hz - 2kHz] if RRmax > 2kHz			
Multimode fibering (M)	Contact factory for availability			
Single mode fibering (F)	Contact factory for availability			
Collimation (C)	Contact factory for availability			
Synchronization output (S)	TTL compatible output signal for synchronization/monitoring			


Available Controller Types						
Model	Туре	Input Power	CDRH			
MLC-03A-DP1	Desktop	100-240 V AC	Yes			
MLC-03A-MP1	Module	12 V DC	No			
MLC-03A-BP1	Board	12 V DC	No			

www.teemphotonics.com

STx series I 3/6



CDRH LASER HEAD MECHANICAL DRAWINGS: STG-03E-1X0, STG-05E-1X0




All information contained herein is believed to be accurate and is subject to change without notice. Teem Photonics may not be held liable for its use. Teem Photonics, its subsidiaries and affiliates, reserve the right to modify or withdraw, at any time and without any notice, specifications, product design, product component. Some options may not be available for all products. Please contact Teem Photonics for details. May 2024.

www.teemphotonics.com

STx series I 4/6



CDRH LASER HEAD MECHANICAL DRAWINGS: STV-01E-1X0, STV-02E-1X0




Il information contained herein is believed to be accurate and is subject to change without notice. Teem Photonics nay not be held liable for its use. Teem Photonics, its subsidiaries and affiliates, reserve the right to modify or withdraw, at any time and without any notice, specifications, product design, product component. Some options may to be available for all products. Please contact Teem Photonics for details. May 2024.

www.teemphotonics.com

STx series I 5/6



CDRH LASER HEAD MECHANICAL DRAWING: STU-01E-1X0



Il information contained herein is believed to be accurate and is subject to change without notice. Teem Photonics hay not be held liable for its use. Teem Photonics, its subsidiaries and affiliates, reserve the right to modify or *vithdraw*, at any time and without any notice, specifications, product design, product component. Some options may or be available for all products. Please contart Teem Photonics for details. May 2024.

www.teemphotonics.com